

INSTALLATION METHOD FOR PRO SERIES HEAD BOLT KITS

Part Number: 234-3711 Application: SB Chevy 6.2L (LT1) V8

1. **Always verify the part number for your application with the part number on the side of box and the part number on the instruction sheet. This will help ensure you have the correct installation procedure for your specific application before installing any components.**
2. Clean and inspect all hardware prior to installation. Look for obvious defects or shipping damages, plus proper fit, length and dimension.
3. To ensure proper thread engagement and accurate torque readings, clean ALL threads in the block. Chase if necessary with ARP Thread Chaser, part number 912-0008 (M12 X 1.75) and 912-0001 (M8 X 1.25).
Note: Some blocks maybe pre-drilled for the M8 bolts and some blocks will need final machine work to install the M8 bolts.
4. Position the chamfered side of the washer on the bolt so it faces the bolt head. This is done to clear the radius on the under head of the bolt. **Note:** Improper installation of the washer will cause premature bolt failure.
5. Lubricate the threads of the bolts, the under head of the bolt and the washers with **ARP ULTRA-TORQUE FASTENER ASSEMBLY LUBRICANT..**
6. Install the cylinder head(s) and check for binding or misalignment.
7. Install the bolts into the cylinder head and tighten them hand tight. **ARP recommends using the ARP ULTRA-TORQUE FASTENER ASSEMBLY LUBRICANT** that is provided with each kit as opposed to motor oil. This is due to higher friction on the bolts as well as inconsistencies in the clamping force of the fasteners when motor oil or other low quality lubricants are used.

PRELOAD (TORQUE) RECOMMENDATIONS

6. Following the manufacturers recommended torque sequence tighten the bolts in three equal steps to the following specifications with **ARP ULTRA-TORQUE FASTENER ASSEMBLY LUBRICANT**.

M12 115 ft lbs

M8 25 ft lbs

Note: ARP Ultra-Torque Fastener Assembly Lubricant has been specifically designed to reduce tension preload scatter and eliminate the need to cycle high performance engine fasteners before final installation. ARP Ultra-Torque far surpasses all requirements offered by previous ARP lubricants in terms of fastener preload repeatability and performance lubricating properties. For more information on ARP Ultra-Torque visit our website at www.arp-bolts.com or call 1 800-826-3045.

Bolt Torque Sequence

