

PART NUMBER**PFF85-802****DESCRIPTION****FRONT WISHBONE REAR BUSH****INSTALLATION GUIDE****Product description:**

This part replaces OEM part number 5Q0407183E.

Contents (parts per pack):



2 x 'A' PU, 2 x 'B' PU, 2 x Sleeves, 4 x Adapter pins, 2 washers, 1 x Grease

*Please read the complete fitting instructions and check package components before fitment.
These fitting instructions are to be used as a guide and in conjunction with workshop manual.
It is recommended that:*

- all work to be carried out by a licensed technician;
 - all safety precautions adhered to;
 - wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.*

Fitting Instructions:

1. Remove the front wish bone from the car and push out the original bush from the arm.
2. Clean any dirt and corrosion from the bore the arm.
3. Apply some of the supplied grease into the bore of the 'A' PU. Insert the metal sleeve into the bore of the 'A' PU making sure the centre hole in the sleeve is visible from the voids of the PU. Use the 'B' PU to plug the side holes on the 'A' PU. Fig A.
4. Press the supplied washer into the 'A' PU. Fig B.
5. Fit the PU into the bore of the arm making sure to position the void as shown in Fig C.
6. Insert and locate the supplied adapter pins into the voids of the 'A' PU and the bore of the metal sleeve inside the PU. Fig C.
7. Fit back arm to the car. Tension all hardware to manufacturers recommended torque settings.

**Fig A.****Fig B.****Fig C.**

INSTALLATION GUIDE**Product description:**

This part replaces OEM part number 5Q0505541A.

Contents (parts per pack):

2 x 'A' Polyurethane Bushes 4 x 'B' Polyurethane Bushes 2 x Stainless steel sleeves 1 x Grease


*Please read the complete fitting instructions and check package components before fitment.
These fitting instructions are to be used as a guide and in conjunction with workshop manual.*

It is recommended that:

- all work to be carried out by a licensed technician;*
 - all safety precautions adhered to;*
 - wheel alignment to be checked and adjusted as required after any suspension work.*
- All fasteners must be tensioned to manufacturer's torque settings.*

Fitting Instructions:

1. Remove the rear trailing arm from the car.
2. Push out the rubber bush from the arm. Fig A.
3. Remove any sharp edges and clean any dirt or corrosion from the arm bore.
4. Fit the new large 'A' PU bush into the arm, with the smaller diameter facing towards the outer face of the arm. Fig B.
5. Insert the two smaller 'B' PU bushes from both sides into the 'A' PU. Fig B.
6. Apply some of the supplied grease in the bore of the bush and insert the stainless steel sleeves into the bore. Fig B.
7. Fit back trailing arm to the car. Tension all hardware to manufacturers recommended torque settings.



PART NUMBER**PFF85-830****DESCRIPTION****LOWER ENGINE MOUNT INSERT****INSTALLATION GUIDE****Product description:**

This part fits OEM part number 5Q0198 037 A as an insert.

Contents (parts per pack):

1 x Polyurethane Insert 1 x Sleeve 1 x Washer 1 x Grease

Please read the complete fitting instructions and check package components before fitment.

These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;*
 - all safety precautions adhered to;*
 - wheel alignment to be checked and adjusted as required after any suspension work.*
- All fasteners must be tensioned to manufacturer's torque settings.*

Fitting Instructions:

1. Access the lower engine mount which is located in the front sub frame under the car.
2. Remove the bolt from the lower engine mount. Fig A.
3. The insert pushes into the voids of the original bush. Remove any flash lines and clean the dirt from the voidings.
4. Slide the new PU insert into the voids of the rubber bush. Fig B.
5. Position the supplied washer on top of the PU insert. Push the supplied sleeve into the bore of the washer. Fig B.
6. Use the original bolt and small washer to secure the PU insert kit into the rubber engine mount. Fig B.
7. Tension all hardware to manufacturers recommended torque settings.



Fig A.



Fig B.